

INSTALLATION Decomur W



...5 EASY STEPS FOR A PERFECT FINISH...

- 1. First we should fit some wooden wads to the ceiling in line (slightly narrower than the beams) and screw them in.
- 2. Then we fit the beam to the wads by screwing the beam to the wooden wads.
- 3. First conceal the joints and screw heads with the mastic for beams and give it texture by light brush-touches of paint..
- 4. Once the mastic has completely dried, apply some paint on it. Mix the color dioxide well and pour it into a bowl or pot, closing it afterwards to avoid its evaporation. Tir the mix continuously and wipe the brush with a cloth before painting.
- 5. Once the paint has dried, scrub the surface with the cloth in order to obtain a perfect finish.

Any additional information you may need, do not hesitate to contact our technical department.